




Magic Girl Topper Control PCB

Thanks for buying one of our custom pinball boards. Please read the below instructions carefully so that you connect up your controller board correctly and do not damage the board and/or your game.

Connections	Name	Info
J1	Power In	Minifit Jr Backbox Connector
J2	RGB Lamp Control Out 1	Topper PCB via 4 pin cable
J3	RGB Lamp Control Out 2	N/A
J4	RGB Lamp Control Out 3	N/A
J5	RGB Lamp Control Out 4	N/A
J6	Mini USB	Data from Computer



Note: In the Game Settings menu under Hardware, you will need to set 'RGB Topper Installed' to yes before the topper pcb will begin showing effects in attract and game play.

